



www.vermontsnowguardcompany.com

LAYOUT PATTERN SUGGESTION FOR SLATE, SHAKE AND SHINGLE ROOFS

Important: Do not install snow guards on roofs with pitches less than 3:12

- ◇ Typical layout is three rows staggered 2' on center.
- ◇ Each row should be 18" to 24" apart.
- ◇ A second or subsequent group of snow guards should be installed at mid-point of the roof on roofs with long runs or steep pitches.
- ◇ Placement and number of snow guards needed will vary depending on the roofing material, pitch, snow load conditions, etc.
- ◇ **Fasteners:** Attach each snow guard with four, 10-gauge stainless steel screws. **Do not use nails!**

For a visual reference guide, see the "Five Steps for Slate Roof Installation" on our website.

Snow guards should be installed by a professional roofing contractor.